



INTRODUCTION: THERE ARE TWO TESTS -BOTH NEED TO BE DONE FOR BEST DIAGNOSIS

1) THE 4-STEP TEST:
THE REGULATOR CONNECTOR IS PLUGGED IN & THE TESTING IS DONE AT THE REGULATOR. SEE ATTACHED TEST



2) THE FULL-FIELD TEST:
THE REGULATOR CONNECTOR IS UNPLUGGED & THE TEST IS DONE AT THE CONNECTOR. SEE ATTACHED TEST



NO VOLTAGE TESTS ARE DONE AT THE DISCONNECTED REGULATOR AT ANY TIME

